



## Shower/Toilet Cubicle Instructions

### Parts List

Canvas	1
Top Cap	1
Ground Sheet	1
Steel Legs	4
Fibre Roof Poles	2
Angles (attached)	4
Guy Lines	4
Towel Rail	1
Shelf Unit	1
Pegs	8
Carry Bag	1



### Instructions

Insert the two fibre glass roof poles into the corner angles on top of the tent and attach the pole clips.

Attach the corner angles to the top of the legs and raise to 2/3 height. Attach pole clips to the legs.

Attach the top cap with the logo to the front, using hook and loop tape to the frame and metal hooks to the loop on the legs. Lift to full height.

Each leg is held captive by a pin on a ring fitted to the bottom of the tent.

Secure the tent to the ground using the tent pegs insuring the base of the tent is square.

Peg out the guy lines.

Hang towel rail and shelf unit and fit the ground sheet if required.

For use as a shower cubicle, there is a hose entry point in the top left hand corner.